

PARTS/TOOLS NEEDED:

	Hole Saw Bit 2", 2-3/4", & 4"	Power Drill w/Phillips Bit	Needle Nose Pliers
DuoFlo Includes: Nylon or SS Hose, Mesh bag, zip ties & Mounting Screws	Not Provided	Not Provided	Not Provided

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.

- Determine the installation location. Use a hole saw to drill the appropriate hole size.

Part #	Mounting Type	Hole/Saw Bit Size
510132	Horizontal Screw Mount	2"
	Horizontal Toggle Mount	2 3/4"
510136 / 510138	Vertical Toggle Mount	4"

- Attach the mesh bag with the zip tie. Use pliers to tighten zip tie securely to the shower cup. Cut the excess zip tie off with scissors.



- Fish out the water line in the unit and attach hose to water supply line. Cinch the zip tie to the hose with needle nose pliers.



- Screw Mount:** Mark the screw holes and pre-drill holes. Insert the holder with the bag into the hole. Screw the holder to the surface. Snap on the bezel to the holder.



- Toggle Mount:** Insert the holder with the bag into the hole. Tighten the toggles by using a drill or screw driver. Snap on bezel to the holder.



- When using the sprayer for the first time, you will need to press the on/off button very hard to get it to engage. This is normal and will not break the button. The button will loosen up after the first few uses.