

DARCHE[®]

DUSK TO DAWN +

INSTRUCTION MANUAL



900-T050801200P
1100-T050801201P
1400-T050801202P

DARCHE.COM.AU

INSTRUCTION MANUAL

CONTENTS

- 1 x Dusk to Dawn+ swag
- 1 x Composite swag pole pack (6 sections that make up 2 poles)
- 1 x Trigger lock spreader pole
- 1 x 70mm high-density foam mattress
- 8 x Pegs
- 2 x Guy ropes
- 1 x Canvas carry bag



SCAN TO WATCH
THE VIDEO


PLEASE NOTE

Prior to first use of the Dusk to Dawn+ swag, it is important to remove the mattress from its compression sleeve and allow it to expand.

Seasoning the swag is not essential but is recommended. For full instructions on seasoning your DARCHE swag, see How to Season Your Swag (page 7).

Step 1

Unroll the swag onto a flat, well-drained area free of sharp objects that may penetrate the swags PVC floor. Assemble the two composite poles.




Remove the first pole bundle (3x pole sections) from the pack:

- 2x END section poles (aluminium sleeve on one end of the pole).
- 1 x MIDDLE section pole (aluminium sleeves on both ends of the pole)

Assemble the END section poles into each side of the MIDDLE section pole sleeves, so all 3 sections are joined to form one pole. Each end of the pole will have the aluminium sleeve to insert the base pin.

Step 2


Feed the pole through the sleeve on the top of the swag and insert it into one of the pins.



INSTRUCTION MANUAL

Step 3



Before attempting to insert the composite pole onto the second pin, ensure the pole sleeve is centred on the pole. Place your palm under the pole end, and push upward until there is a gap between the pole end and the second pin. Insert the second pin.



IMPORTANT: DO NOT BEND THE POLE TO INSERT THE SECOND PIN.




Repeat this process for the other pole whilst correcting the swag skin as you assemble.




Step 4

Clip the swag to the composite poles. A good technique for attaching the clips is to alternate from one side to the other - top left, then top right, second left and then second right and so on.




Step 5

Stretch out the base of the swag to ease assembly when placing the spreader pole. Insert the spreader pole into one of the centre eyelets.




Step 6

Release the trigger to extend the spreader pole and insert into the eyelet at the other end. Tension the bar to stretch the swag into shape then lock into position.



INSTRUCTION MANUAL

Peg out and tension the guy ropes if required. Your Dusk to Dawn+ swag set up is now complete.



PACK DOWN

1. Partially close all the zips, door covers and window flaps, leaving them slightly open will allow for the air to escape while rolling up. Remove pegs and guy ropes if used.
2. Release the trigger of the spreader pole and remove it from the eyelets.
3. Unclip the swag from the composite poles one end at a time.
4. Leave the MIDDLE section pole within the foot end sleeve. If room permits slide the other poles inside the swag sleeve to secure.
5. While the swag is laid out flat, bring any overhanging canvas and ropes into the centre of the swag. Beginning from the Hutch end of the swag, fold the Hutch over onto the main body section then begin rolling up the swag. Roll the swag as tightly as possible to achieve a compact roll. Tip: Using your knees, or two people while rolling, will assist in getting the swag as compact as possible. Just before completing the rolling process, place all the disassembled poles between the fabric and continue rolling process to the end.
6. Bring the two compression straps together and loop through the double D-rings, do not over tighten the straps.

NOTE

Allow a wet or damp swag to dry thoroughly before pack down. If this is not possible, unroll swag as soon as possible. Allow to fully dry out before re-packing and storing.

SPARE PARTS LIST

For a full list of Spare Parts available refer to DARCHE.COM.AU

HOW TO SEASON YOUR DARCHE SWAG

The best way to season your swag is to set up outdoors and completely soak the exterior material of the swag with a hose. Allow the swag to dry completely. Repeat this process 2-3 times. Seasoning the swag will allow the canvas material to swell and will help to fill any stitching holes, providing an additional level of weather protection. Ensure the swag is completely dry before packing away.

CARE & STORAGE INSTRUCTIONS

1. Remove dirt with a soft brush and cold water after use.
2. Do not clean with soap, detergent, petrol, oil or solvents.
3. Ensure swag is completely dry before storing.
4. Do not store directly on concrete floors. A dry shelf in your shed or a cupboard is a perfect spot for your swag when not in use.
5. If spot mould is visible, brush it off with a stiff bristle nylon brush and vacuum the area to get rid of any residual spores.
6. Leaving your swag rolled too tightly for long periods of time may result in the mattress taking a while to bounce back. If it's been a while since your last adventure, open your swag a few days before you leave and allow the mattress to expand. Re-pack your swag and have a great weekend.

MOISTURE/CONDENSATION

Condensation is a natural occurrence in confined areas like swags/tents due to the body releasing more moisture than the canvas can dispose of in cold weather. To minimise the chance of condensation, we recommend slightly opening the window to enable airflow on cold nights.

I N S T R U C T I O N M A N U A L

Designed and tested in Australia for Australian conditions.

A brand by Charles Parsons.

Telephone 1300 367 695 | Email: info@DARCHE.com.au

75 Heyington Avenue, Thomastown VIC 3074, Australia.

DARCHE: LEADERS IN OUTDOOR DESIGN. PROUDLY AUSTRALIAN.

Due to our policy of continual product development,
the specifications, colours and features may vary.

V1-July 2021



D A R C H E . C O M . A U