

## **PRODUCT DATA SHEET**

NORGLASS LABORATORIES PTY.LTD.

A.B.N. 92 001 807 245

P.O. Box 312, Neutral Bay. NSW 2089 Australia

59 Moxon Road, Punchbowl NSW

Ph: 61 2 9708 2200 Fax: 61 2 9796 3069

Email: norglass@bigpond.net.au

www.norglass.com.au



**DESCRIPTION:** A blended lightweight extender for Norglass epoxies.

**USES:** For filling and fairing surfaces.

PROPERTIES (at 20°C)

**COLOUR:** Dry white fluffy Powder

**TOXICITY:** Nor Hazardous according to the criteria of Worksafe Australia

FINISH: N/A

**COVERAGE:** Varies according to Epoxy Resin mix.

**DRYING TIME:** 3-4 hours

**RECOATING:** Overnight

**POT LIFE:** Subject to resin volume.

MIXING RATIO: Discretionary – Usually 1:1 mixing ratio by volume

THINNING: N/A

WEIGHT/LITRE: 100g

**VOLUME SOLIDS:** N/A

FLASH POINT: N/A

CLEAN UP: NORGLASS EPOXY THINNER

U.N. NUMBER: NOT ALLOCATED



**PREPARATION:** Add NORCELLS to the base component and mix thoroughly before adding the hardener

component. Spread the mix on a board or palette to reduce the thickness of the mix

before applying to minimize heat development.

**APPLICATION:** Apply to the surface with a squeegee, trowel or spatula. On vertical surfaces, the

consistency should be made stiff enough to prevent sagging.

TRANSPORTATION: Non Hazardous.

**PRECAUTIONS:** Avoid inhaling its dust. Mix in a still area as the lightweight powder will move quite freely

in air. Use protective clothing. Mask and goggles essential.

FIRST AID: If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 13 11 26 or

(NZ) 0800 764 766 and have label information ready.

If swallowed DO NOT induce vomiting. Give large quantities of water or milk. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and easy to do and continue rinsing. In case of skin contact, remove contaminated clothing and wash skin thoroughly. If breathing difficulty arises remove to fresh air. Apply artificial respiration if not breathing.

SPECIAL INSTRUCTIONS: